

Hamburger Press Model GRF100 and GRF130



Grange Product Range

Mincing Equipment

Bandsaws

Food Processors

Juicers

Light Kitchen Equipment

Mixers

Slicers

Wrapping Equipment



Installation


- Install the machine onto a solid, stable, non-slip surface. This area should be large enough to allow easy access and cleaning.
- Put the cellophane discs into the holder at the top of the machine.

Operating the Hamburger Machine


- Put one cellophane disc into the holder.
- Place a small quantity of minced meat on top of the cellophane disc, according to the thickness required.
- Place another cellophane disc on top of the minced meat.
- Pull the lever down to form the hamburger.
- Lift the lever fully, which will lift the hamburger for easy removal.

Cleaning

• Carefully clean the machine with damp cloth and then wipe off with a dry cloth needed in operation.







GRF130





New South Wales and Victoria

Reliable Food Equipment 02 9620 4944 rfesales@gmail.com

Queensland

Chopology Food Equipment 0418 194 597 jryeates@optusnet.com.au

South Australia

GaP Solutions 08 8408 8150 sales@gapsolutions.com.au

Tasmania

Quality Equipment 03 6234 8300 quality.equipment@tassie.net.au

Western Australia

MBL Food Services 08 9334 9600 info@mbl.com.au



it's customer satisfaction'